

QDDISC01 Universal Disc Remote Control Brand Code List

Brand	Code	Model
AIER PRINCE	066, 067	DVD998, VCD+MP3
AIWA	140, 315, 316, 317, 318, 319, 320, 321, 322, 323, 324	RC-ZVL01, RC-6AS01, 6AT05, 8AC01, 8AT05, ZAS01, ZAT05, ZAS08, T1400KE, TN380B, TN999
AKAI	006	AKAI
AMOISONIC	093, 094, 096, 121, 267, 268, 269, 270, 271	VURRC215, VURRC217, VURRC214 DVD-RC-211, RC-211T, RC-202 010, 010G, 012, 003, 001
AVLIGHT	131, 142, 143, 144, 145	DVD
BBK	018, 021, 027, 028, 033, 048, 078, 133, 236, 237, 238, 239, 240, 241, 242, 386, 387	RC017-03, AB903K, RC017-06, AB9903, RC017-008, DVD-YK02, DVD-YK03, DVD-YK06, AB-005B, AB-007A, AB007K, AB903K, DF0058, RCU-H, RC-101
BLANTER	064, 065	DVD
CAINI	347	VCD
CHANG HONG	122, 123, 124, 274, 275, 276, 277	DVD-DK5N, DVD-DK1, DVD-DK4, VK1A, VR4A
DESAI	026, 074, 099	DVD D88329
DIHE	070, 077, 087, 346	KM-19, VRC200, DVD
DINGTIAN	111	RMC2100BDS, RMC2000BDS
	349	
DONGDA	342	
DONGPENG	343	CVD-970
HAIER	098,135,136	DV-300, HaierDVD-1, HaierDVD-2
HAOJI	068	DVD668E
HISENSE	131, 001, 120, 141	DVD-YKV005, DVD-RC68, SVCD, HY-2011
HITACHI	299	SV-RMW1
HITER	090	DV-210
HUABAO	029, 061, 062, 063	DVD
HUAJIA	108	DVD
IDALL	112, 243, 244, 245, 246, 247, 248, 249, 250	DVD, 308, 320, 330, 350, IV-3DBK, IV-360BK, IV-361BK, IV-620, IV-730BK, IV-830BK, IV-820BK, RM-1, SVCD
JIABAO	341	MP3 DVCD
JINGE	345	-
JINGE WANGPAI	020, 031, 059, 060, 076	RC-0304, RC-0215, RC-0216, RC-821
JINGWEI	011	DVD
JINWANG	035	PDVD-828
JINZHENG SHUMA	382	VCD-J306/TJ308

Brand	Code	Model
JVC	045, 146, 328, 329, 330, 331, 332	RM-SXVOOV, RM-XVM557U, RM-SXV010X, RM-RMV5U, XL-M705, RM-SEV808TU, RXUT4R, SXSUV1U
JX2026G	355	X-9953
KENWOOD	075, 325, 326 327	VD, RC-L0200, L0300, F0501, F2
KETAI	- 030	VD
KONKA	125	182
LG	008	VD-1, DVD-2V, DVD-3
LINGSHUMA	036, 076	VD
MALATA	002, 009, 023 024, 073, 085, 135, 137, 146, 230, 231 232 233, 234, 235	DVD-N960, DVD, MVD, VP-N28, N30, N28B, N28K, 28F, N28P, N30B
MASHILAN	338	RS500LV
NINTAUS	003, 071, 079, 080, 081, 082, 113, 114, 115, 116, 258, 259, 260, 261	DVD-NSOS, DVD-N999, DVD-N990, DVD- N715, DVD-N926, DVD-N769, DVD-N816 DVD-N768i DVD-N800 DVD-N736, DVD-N736A, DVD-N108FD, DVD-N990A, DVD-N999A, DVD-N9663, CD-J301, J303, J306, J308, 100, 7836H, VD-8801, N350D,N350, VCD-J7001H, VCD-6803H, DVD-N768, DVD-N700, 701, N926F
OKON	072	DVD
ONKYO	043, 311, 312	RC-375DC, RC-2875, 375DV
PANASONIC	014, 085, 282 283 284, 285, 286 287 288 289, 290 291, 292	FVR7621030,DVD-VEQ2392,VCD-A300, RAK-LX140WH, SL208WH, SLA04SH, SL429WH, SC955WK, EUR642180, EUR642181, EUR642191, EUR644344, EUR644854, EUR644973
PANDA	038, 051, 052 053 379, 380, 381	RC-178, RC2002G, RC2001D-1, VIDEO-CD 2858, 2838
PEACOCK	335	PV9681A
PHILIPS	012, 131, 147, 148, 149, 279, 280 281	DVD, RC9903, RC9904, RC2K01, RC2K02, RCL9901, 9805B
PHISONEEP	350	
PIONEER	044, 134, 304, 305, 306, 307, 308, 309, 310	DVD,VXX2800, CU-S0013, CU-DV003, CU-CLD145, 151 PWW1168,CU-XR061,PD094,PD100
QINGHUA TONGFANG	056 057	DVD
QISHENG	005 037 130 262 263 264 265 266	OVD-808, IRC-808A, IRC-801, 3039, 3030D, 3000, 3020A, 3028
RMS	351, 352	IRC-3000
ROWA	340	1V-730BK, 830BK
SAMSUNG	004, 017, 049, 136, 139, 334	O0092M, 00094Z, DVD
SANSHUI	013, 046, 333	OV-4, DVD, RS-5147

Brand	Code	Model
BAST	020, 059, 060, 076, 127, 129, 272, 273	RC-0304, RC-0215, RC-0216, RC-281, KC-0117, RC-0215A, RC-821, RC-9603
SHARP	313, 314	MV-K7000, CD-X15
SHIDA	100	SRC-106
SHINCO	001, 010, 088, 251, 252, 253, 254, 255, 256, 257	RC-028, RC-002, 125, 005 007, 12E, 12F 12B, VCD-719, 08C, 006, 012 16H, 260, 12G, 16A, IRC-380, DVD-600, DVD-380, DVD-280, DVD-200, DVD-280H, DVD-280A
SIGADB0	384, 385	
SKYWORTH	022, 025, 026, 032, 034, 058, 101, 102, 104	DVD PLAYER DVD-650, DVD PLAYER2
VCD	353	
SONY	040, 293, 294, 295, 296, 297, 298, 377	DVD, VCP-K10, RMT-M40A, RMT-D109E RM-S343, RM-S530, RMT-990
SOYA	150	K-870C
SUBOR	353	VCD
SVA	001 088 378	DVD-260i RC-212A, RC-212
-	000, 015, 039, 054i	RC BOI REM 1
TCL	055, 103, 278	RC-802, RC-801
THIMS0N	083	DCD
-		
TIANLONG	042 339	RC-543
TOSHIBA	041,069, 300, 301, 302, 303	SE-R0037,SE-R00049, RM-LS, VC-659, VC-800K
	007	MP3
VICTOM	354	RM-SVD701
V0CTOR	047, 084	RM-SVD701
WANYAN	110, 135	DVD-1, DVD-3
WEIFA	050	DVD
XIANHUA	336	VP-1010
XINTIANLI	117	DVD
YINGZHIBAO	348	
YITONG	337	RM2004
YOUR ISHENG	107, 118	BS-K503DV, BS8810
YUXING	097, 151	DVD, DR-001
ZHAOWEI	344	
Other DVD	016, 019, 106, 119, 152	EM-228, KP702, KM-123, DVD
Other models	356, 357, 358, 359, 360, 361, 362, 363, 364, 365, 366, 367, 368, 369, 370, 371, 372, 373, 374, 375, 376, 388, 389	RC-010A (18), ANB-999, RM2004, A9815